


Rudolf-Diesel-Str. 21-23 D-33178 Borchen

Telefon: +49 (0) 5251 /691 69 0 Telefax: +49 (0) 5251 / 691 69 11 E-Mail: info@waptech.de Internet: www.waptech.de

Repair Instructions

Disc brake with oil storage



Disassemble the brake unit before dismantling.

Dismantling:

- 1.) Remove the clamping pin (Pos.1) and brake disc (Pos.2).
- 2.) Undo the sealing screw (Pos.10) and drain the bearing oil. The oil must be disposed of in accordance with legal provisions.
- Remove the sealing ring (Pos.9).

 3.) Unscrew the axle cap (Pos.3) in an anti-clockwise direction and remove the O-ring (Pos.4).
- 4.) Dismantle the split pin (Pos.5) and unscrew the crown nut (Pos.6) from the thread.
- 5.) Pull the wheel hub (Pos.8) and bearing (Pos.7 and 11) off the axle stub.
- 6.) Dismantle the shaft sealing ring (Pos. 12).
- 7.) Using a hammer and chisel (Pos.13), strike the adjusting ring and pull it off the axle stub.

Assembly:

- 1.) Strike the adjusting ring (Pos.13) onto the axle stub.
- 2.) Press the shaft sealing ring (Pos.12) and the bearings (Pos.7 and 11) into the bearing retainers belonging to the wheel hub (Pos.8) and assemble onto the axle stub.
- 3.) Tighten the crown nut (Pos.6) so far that the running of the wheel is decelerated slightly. Then turn the nut back to the next available split pin hole, max. 30°.
- 4.) Assemble the split pin (Pos.5).
- 5.) Insert the O-ring (Pos.4) and tighten the axle cap (Pos.3) by hand.6.) Fill the bearing oil (Pos.14), insert the sealing ring (Pos.9) and tighten the sealing screw (Pos.10) by hand.
 - The correct oil level is shown by the min. / max. display on the axle cap (Pos.3) and should ideally be between the two markings.
- 7.) Assemble the brake disc (Pos.2) with the clamping pin (Pos.1) on the wheel hub (Pos.8).

Pos.		Designation				
1	Clar	Clamping pin				
2	Brak	Brake disc				
3	Axle	Axle cap				
4	O- ri	O- ring Ø48				
5	Split	Split pin				
6	Cro	Crown nut				
7	Bea	Bearing				
8	Whe	Wheel hub				
9	Sea	Sealing ring				
10	Sea	Sealing screw				
11	Bea	Bearing				
12	Sha	Shaft sealing ring				
13	Adju	Adjusting ring				
14	ESS	ESSO Mobil Fluid 422				
15	Ada	Adapter ring				
16	O- ri	O- ring Ø66				
·		Datum	Name			

		Datum	Name
Nummer	Bearb.	09.02.2015	Schneider
MA-162_E	Prüfer	10.02.2015	Joachim

All work must be performed by specialist staff.